





Illustration.



1. Select no scaling when printing.
Check the scale of the distance
250 mm is correct.

Example

2. Place the boot as shown
in the illustration. Make sure
the boot tip is exact on the
line



5. Check if you have small
or large binding (written on
the binding). Use the
respective holes.

3. Read the value at
the back of the heel
and use the
respective holes for
mounting of the heel.




4. Use the value reading in
step 3, and match this with
the ski's centermark.











250 mm

NB!

Small Large



Holes for binding plate 6 pcs



Holes for support plate 2 pcs

- 250
- 260
- 270
- 280
- 290
- 300
- 310
- 320
- 330
- 340
- 350
- 360




250 mm





250 mm

NB!



Holes for support plate 2 pcs



← **Boot sole length (mm) = Ski centermark**

Scale for the position of binding plate and AT- slider

250 mm

